

DEPARTURE ROUTE DESCRIPTION



TAKE-OFF RWY 31: Climb straight ahead to RK NDB thence.....

RE3: Turn right, intercept the 014° bearing from RK NDB, continue climb via assigned route.
Cross RENSA IRE 11 DME above 3500, IRE 40 DME at or above 5000.

SU3: Turn right, intercept the 360° bearing from RK NDB, continue climb via assigned route.
Cross IRE 25 DME at or above 5000.

KEF3: Turn left, intercept KEF VORTAC R-076 inbound to KEF VORTAC, continue climb via assigned route.

SA3: Turn right, intercept the 028° bearing from RK NDB, continue climb via assigned route.
Cross SA NDB above 3600, LEIRA at or above 5000.

PA3: Turn right intercept the 350° bearing from RK NDB, continue climb via assigned route.
Cross IRE 40 DME at or above 5000.